

Setting up your projector, elmo and laptop

Look at the following diagrams to set up your projector, Elmo and notebook computer.

You will need five items: 1. your projector; 2. your Elmo; 3. your computer; and 4. two connecting cables. The two cables are the same on both ends, so it does not matter end you plug in.

What you need:

1. Your projector



2. Your Elmo


3. Your laptop



4. Two video cables

The steps to connect and activate the setup are:

1. Connect your Elmo to your projector – connect the first cable to the **RGB out** port on the Elmo and plug the cable into the **computer in** port of the projector.
2. Connect your computer to the Elmo – connect the second cable to the **RGB in** port of your Elmo and plug the other end of the cable into the **video (screen icon)** port of the computer.



You are not quite done. After you have connected the three components with the two cables, make sure to:

1. Power on the Elmo and press the **Camera** button to project from your Elmo.
2. To switch from the Elmo to the laptop, press the **PC** button on the Elmo. The signal will then pass from the computer, through the Elmo to the projector.
3. If no image appears, hold down the **Fn** key on your laptop and then tap the **F7** key that has the screen icon on it. This will give you a dialog box that allows you to set your laptop to project its screen image.